

v1.0

Checking Inserts on Si Mixers with No Audio Output

19-Jan-23

Question:

Why do mixer outputs or individual channels have no audio even though there is meter movement?

Answer:

There are 22 Inserts available on Si mixers. These create a “loop” to Send and Receive from another device and can be Inserted on any channel, and any Output. If there is an active Insert assigned, and that loop is not complete (plugin broken, patch bad, device itself not passing audio), then the audio chain will be broken at that point of insert. To check, select the Insert in option on the screen. If you see any Inserts assigned, try momentarily setting them to “Unassigned” and see if audio flow returns. If this fixes the issue, then you must investigate the Insert or Plugin for issues before re-inserting.

About HARMAN Professional Solutions

HARMAN Professional Solutions is the world's largest professional audio, video, lighting, and control products and systems company. Our brands comprise AKG Acoustics®, AMX®, BSS Audio®, Crown International®, dbx Professional®, JBL Professional®, Lexicon Pro®, Martin®, and Soundcraft®. These best-in-class products are designed, manufactured and delivered to a variety of customers in markets including tour, cinema and retail as well as corporate, government, education, large venue and hospitality. For scalable, high-impact communication and entertainment systems, HARMAN Professional Solutions is your single point of contact. www.harman.com