

# RUSH Batten- Setting DMX mode and Master-Client

## Setting DMX mode and Master-Client Operation

The fixture can be set to operate in 13 channel or 80 channel DMX mode, or in Client mode for Master-Client operation. 13 channel mode is the normal control mode. 80 channel mode allows individual RGBAW+UV control of each pixel.

### Setting DMX Mode:

1. In the DMX FUNCTIONS menu select DMX MODE and press ENTER.
2. Select 13CH (default), 80CH or CLIENT.
3. Press ENTER to confirm or press MENU to exit.

#### About HARMAN Professional Solutions

HARMAN Professional Solutions is the world's largest professional audio, video, lighting, and control products and systems company. Our brands comprise AKG Acoustics®, AMX®, BSS Audio®, Crown International®, dbx Professional®, DigiTech®, JBL Professional®, Lexicon Pro®, Martin®, and Soundcraft®. These best-in-class products are designed, manufactured and delivered to a variety of customers in markets including tour, cinema and retail as well as corporate, government, education, large venue and hospitality. For scalable, high-impact communication and entertainment systems, HARMAN Professional Solutions is your single point of contact. [www.harman.com](http://www.harman.com)