Please see the downloadable file 994-DL1-Get IP Address of Touchpanel from code.axs. This example demonstrates the use of the NetLinx structure IP_ADDRESS_STRUCT to define a variable and then store information received from the GET_IP_ADDRESS NetLinx function. You can then use the .IPADDRESS operator on the variable you defined of type IP_ADDRESS_STRUCT to obtain the IP Address of the Touchpanel. See Help..Netlinx Keywords Help..Index..GET_IP_ADDRESS for an explanation of the structure elements.