

Ether2DMX8 License Key Missing Error Message

“License Key Missing” shown on the display:

If you see this error message shown on the display it is possible that the license card is no longer located correctly in the card slot.

To fix:

Remove all 5 screws from the top panel.

Remove the top-centre screw from the front panel.

Remove the top panel.

Locate the SD Card on the main processing pcb.

Check the card is located securely by pushing the card into the slot.

It should click into place and it should not be possible to slide the card out by ONLY pulling at it..

Pushing on the card again will cause it to eject.

If this does not correct the issue please contact your local distributor for repair.

About HARMAN Professional Solutions

HARMAN Professional Solutions is the world's largest professional audio, video, lighting, and control products and systems company. Our brands comprise AKG Acoustics®, AMX®, BSS Audio®, Crown International®, dbx Professional®, DigiTech®, JBL Professional®, Lexicon Pro®, Martin®, Soundcraft® and Studer®. These best-in-class products are designed, manufactured and delivered to a variety of customers in markets including tour, cinema and retail as well as corporate, government, education, large venue and hospitality. For scalable, high-impact communication and entertainment systems, HARMAN Professional Solutions is your single point of contact. www.harmanpro.com