

Audio Between Signature Series Mixer and PC not Bi-Directional

If audio between the Signature mixer and the PC is only working in one direction, you need to replace the driver Windows is using. Remove current driver and install the Soundcraft Notepad driver found here:
<https://www.soundcraft.com/en-US/software/notepad-firmware-and-control-panel-setup-windows-v2-0-4-windows>

About HARMAN Professional Solutions

HARMAN Professional Solutions is the world's largest professional audio, video, lighting, and control products and systems company. Our brands comprise AKG Acoustics®, AMX®, BSS Audio®, Crown International®, dbx Professional®, DigiTech®, JBL Professional®, Lexicon Pro®, Martin®, and Soundcraft®. These best-in-class products are designed, manufactured and delivered to a variety of customers in markets including tour, cinema and retail as well as corporate, government, education, large venue and hospitality. For scalable, high-impact communication and entertainment systems, HARMAN Professional Solutions is your single point of contact. www.harman.com