

v1.0

## Buttons Greyed Out on an Si Mixer

15-Apr-22

**Question:**

My output/input button is greyed out on the patching page, how do I fix this?

**Answer:**

You can only access outputs and inputs if you have the item selected, like an input channel or an output buss. Select the output or input you want to change and then the corresponding selection will be available.

If you're trying to route for recording, the direct out patch is found on the Input Patching screen.

**About HARMAN Professional Solutions**

HARMAN Professional Solutions is the world's largest professional audio, video, lighting, and control products and systems company. Our brands comprise AKG Acoustics®, AMX®, BSS Audio®, Crown International®, dbx Professional®, DigiTech®, JBL Professional®, Lexicon Pro®, Martin®, and Soundcraft®. These best-in-class products are designed, manufactured and delivered to a variety of customers in markets including tour, cinema and retail as well as corporate, government, education, large venue and hospitality. For scalable, high-impact communication and entertainment systems, HARMAN Professional Solutions is your single point of contact. [www.harman.com](http://www.harman.com)