

v1.0

Output Fader not Controlling Main Outputs

26-Jul-22

Question:

What causes the Output Fader to turn red and stop controlling the Main Outputs?

Answer:

The Fader and the Monitor output controls have been swapped to use the mixer in a Monitor console configuration. To change back to default:

- Select the Menu button
- Select Monitor Setup page
- Select LR/Monitor Swap and disable it

This should return the Output Fader to normal operation.

About HARMAN Professional Solutions

HARMAN Professional Solutions is the world's largest professional audio, video, lighting, and control products and systems company. Our brands comprise AKG Acoustics®, AMX®, BSS Audio®, Crown International®, dbx Professional®, DigiTech®, JBL Professional®, Lexicon Pro®, Martin®, and Soundcraft®. These best-in-class products are designed, manufactured and delivered to a variety of customers in markets including tour, cinema and retail as well as corporate, government, education, large venue and hospitality. For scalable, high-impact communication and entertainment systems, HARMAN Professional Solutions is your single point of contact. www.harman.com