



vI.0 Setting up the LYRA in Skype

3-Feb-23

ASIO Driver Setup for Windows

It is recommended that you download the latest ASIO driver from <u>www.asio4all.com</u>.

Install the ASIO Driver by following the instructional prompts on the Windows computer.

When prompted to "choose components", make sure "Off-line Settings" is selected.

ASIO4ALL 2.14 Setup		– 🗆 🗙
Choose Components Choose which features of ASIO4A	LL 2.14 you want to install.	
Check the components you want t install. Click Next to continue.	o install and uncheck the comp	oonents you don't want to
Select components to install:	ASIO4ALL v2 ReWuschel Off-Line Settings	Description Position your mouse over a component to see its description.
Space required: 601.0KB		
ASIO4ALL 2.14 (NSI5 v2)		
	< Back	Next > Cancel

Open the ASIO Off-line Settings menu from the Windows Start menu.



Setting up the LYRA in Skype



Click the wrench in the bottom corner to open advanced settings.

ASIO4ALL v2.14 - www.asio4all.com - feedba	ck@asio4all.com ×
WDM Device List	Latency Compensation
 Realtek (R) Audio Realtek HD Audio Line input Realtek HD Audio output Realtek HD Audio Stereo input Realtek HD Audio Mic input Realtek HD Audio Stereo input Realtek HD Audio Stereo input Realtek HD Audio Stereo input Realtek HD Audio Mic input	In: 32 Samples
	Out: 32 Samples
	Options
	Hardware Buffer (Does not always work)
	Kernel Buffers: 2
	Always Resample 44.1kHz <-> 48kHz
	Force WDM Driver To 16 Bit
ASIO Buffer Size = 512 Samples	
	- 💮 🏹 <

Make sure the AKG C44USB Microphone is selected as the active device (both inputs and outputs), and make sure all other devices are not active.

ASIO4ALL v2.14 - www.asio4all.com - feedback@	asio4all.com ×
WDM Device List	Latency Compensation
	In: 32 Samples Out: 32 Samples Options Hardware Buffer (Does not always work) Kernel Buffers: 2 Always Resample 44.1kHz <> 48kHz Force WDM Driver To 16 Bit
	- 💎 🏹

From this menu, you can set all of the buffer settings as desired.

NOTE: TURN OFF THE MICROSOFT SYSTEM SOUNDS ONCE YOU INSTALL THE ASIO DRIVER AS THE SYSTEM SOUNDS MAY INTERFERE WITH ASIO DEVICE COMMUNICATION.

Setting up the LYRA in Skype

Skype Setup for Windows

Open the Skype application.

From the Skype Settings menu, select the Audio & Video tab.

Select the AKG C44USB as the microphone, and if desired, select the AKG C44 USB as the Speaker output.

HARM/

You can test the audio by selecting "Test audio" from the Audio & Video menu.

×	VIDEO
Settings	Camera
5	O No device found. <u>Learn more</u> about fixing this issue.
Account & Profile	AUDIO
ⓒ} General	Microphone Microphone (2- AKG C44-US8 Microphone) ~
Appearance	••••••••••••••
Q Audio & Video	Automatically adjust microphone settings
& Calling	Speakers Headphones (2- AKG C44-USB Microphone) ~ 0 1 2 3 4 5 6 7 8 9 10
Messaging	
. Notifications	▷ Test audio
Contacts	Unmute for incoming calls
(j) Help & Feedback	Ring on additional device
	& Make a free test call

You are now ready to use the LYRA with Skype.


Setting up the LYRA in Skype

Skype Setup for MAC

Open the Skype application.

Go to Skype > Audio & Video Settings.

Select AKG C44USB as the Microphone and Speakers.



HARM

You are now ready to use the LYRA with Skype.

About HARMAN Professional Solutions

AKG

HARMAN Professional Solutions is the world's largest professional audio, video, lighting, and control products and systems company. Our brands comprise AKG Acoustics[®], AMX[®], BSS Audio[®], Crown International[®], dbx Professional[®], JBL Professional[®], Lexicon Pro[®], Martin[®], and Soundcraft[®]. These best-in-class products are designed, manufactured and delivered to a variety of customers in markets including tour, cinema and retail as well as corporate, government, education, large venue and hospitality. For scalable, high-impact communication and entertainment systems, HARMAN Professional Solutions is your single point of contact. www.harman.com

HH

exicon

Martin

Soundcraff