

## Keyboard Control

For users mixing with a device that has a keyboard, please see below a set of easily accessible key commands, making it quick and efficient to access the most used features on the mixer.

<b>[1]</b>	DASHBOARD
<b>[2]</b>	MIX/GAIN
<b>[3]</b>	EDIT
<b>[4]</b>	AUX SENDS
<b>[5]</b>	FX SENDS
<b>[6]</b>	MEDIA
<b>[7]</b>	SETTINGS
<b>[8]</b>	SNAPSHOTS (Same as click in NAV Display)
<b>[9]</b>	SLIDEOUT
<b>[SPACEBAR]</b>	SLIDEOUT.
<b>[Q]</b>	FX RETURNS
<b>[W]</b>	SUB GROUPS
<b>[E]</b>	AUX MASTERS
<b>[A]</b>	MUTE ALL
<b>[P]</b>	PRESETS
<b>[F]</b>	MUTE FX
<b>[M]</b>	MUTE
<b>[S]</b>	SOLO
<b>[C]</b>	CHANNEL POP UP MENU
<b>[~]</b>	UNDO (last page viewed)
<b>[Left arrow]</b>	Jump 1 channels to the left
<b>[Right arrow]</b>	Jump 1 channels to the right
<b>[Up arrow]</b>	Jump 8 channels to the left
<b>[Down arrow]</b>	Jump 8 channels to the right
<b>[TAB]</b>	Toggle through the tabs inside EQ, DYN, FX, AUX.