vI.0



How to Access Windows File Explorer on Vi Series Consoles 23-Mar-23

How to access Windows File Explorer on the Vi series consoles?

Attach a USB keyboard and a USB mouse to the Vi (Apple keyboards and mice are not supported). The USB ports on the front or rear of the console may be used.

Simultaneously press "Ctrl + Shift + Esc". This key command should bring up the Windows Task Manager.

In the Task Manager go to "FILE" and choose "New Task" from the dropdown menu.

	Windows Task Mana File Options View	ger Help	* LI II					
	New Task (Run)		Performance Networking Users					
Mix 1 - 8	Exit Task Manager	110	Description	Status	Group			·
1 2 3 4 25 26 27 28 6 20 51 52 73 11 15 76 Aux 1 0.0 dg	AeLookupSvc ALG AppHotSSvc AppIr6o AppMont aspnet_state AudioEndpointBuilde AudioEndpointBuilde AudioEndpointBuilde BEE BEE BETS Browser bthserv	1380 - 836 1052 1212 896	Application BitLocker D Base Filteri Computer Bluetoth Computer Bluetoth	Stopped Stopped Running Stopped Stopped Stopped Running Stopped Running Stopped Running Stopped Running Stopped	netsvcs netsvcs N/A LocalSystemNe		n	
SOLO							Service	s
Group 9 0.048 Grp 9 SOLO	Runs a new program 0.0 de Grp 10 SOLO SOLO SOLO SOLO		U.U dB Grp 12 SOLO	Grp 1:	3 Gri	D dB p 14	0.048 Grp 15 SOLO	0.048 Grp 16
VCA1	VCA2 V	CA3	VCA4	V	CA5	VCA6	VCA7	VCA8

This should bring up the Create New Task window.

	📧 Windows Task Ma	nager				
	File Options View	v Help				
	Create New Task		-	×		
Mix 1 - 8	Open: explored	, and Windows will open r		• Impersonatio	'n	
19 50 51 52 13 71 75 76	BDESVC BFE	OK C		kRestricted kRestricted		
Ацх 1 0.0 ав Ацх 1	BITS Browser bthserv	Backgroun. 896 Computer . Bluetooth .	Stopped netsvcs Running netsvcs			•
SOLO					Services	
Group 9	Processes: 51 C	PU Usage: 19% F	hysical Memory: 41%			ai
C.O.dB Grp 9	0.0 dB Grp 10 Grp 1 SOLO SOL	11 Grp 12	0.0d8 Grp 13	0.0 dB Grp 14	0.048 Grp 15	0.0 d8 Grp 16
VCA1	VCA2	VCA3 VCA	4 VCA5	VCA6	VCA7	VCA8

How to Access Windows File Explorer

on Vi Series Consoles



Type "explorer" and click "OK".

There is an alternate method to open File Explorer; Once the USB keyboard and mouse are connected, type "loadexplorer". This will bring up the Windows Taskbar.

	ovu	OVL	DESK LOCAL D STAGEBOX HIQNET UAD
	0 36	36	Front-of-House
		1 20	
Mix 1 - 8 N	Mix 9 - 16 Mix 17 - 2	4	
	o	0	
1 2 3 4 5 6 7 8 A	9 10 11 12 13 14 15 16	A 17 18 19 20 21 22 23 24	
		a B	
25 26 27 28 29 30 31 32	33 34 35 36 37 38 39 40	11 12 13 11 15 16 17 18	
C	с С	C	
19 50 51 52 53 54 55 56 0	57 58 59 60 61 62 63 64	65 66 67 68 69 70 71 72	
. 13 14 15 16 11 18 19 80		B9 90 91 92 93 94 95 96	
Aux 1 🔍 Aux 2 🔍	Aux 3 Aux 4 Aux	Aux 5 🔍 Aux 6 🔍	Aux 7 🔜 Aux 8 🔜
О.Оав О.Оав Ашх 1 Ашх 2	О.Оав О.Оав Ашх 3 Ашх 4	0.0ав 0.0ав Ашх 5 Ашх 6	0.0ав 0.0ав Ашх 7 Ашх 8
Group 10	Group 11 🔜 Group 12 🔜	Group 13 🔜 Group 14 🔜	Group 15 🔜 Group 16 🔜
0,0 dB 0.0 dB	0.0 ав 0.0 ав Grp 11 Grp 12	0.0 dB 0.0 dB 0.0 dB 0.0 dB 0.0 dB	0.0 dB 0.0 dB Grp 15 Grp 16
SOLO	SOLD	SOLO	SOLO
			4 5:08 AM
	*	VOR8 VOR8	▲ (¹)) 5:08 AM 6/23/2015

Now you can click on the File Explorer icon. If you cannot find your mouse cursor, tap the "Ctrl" on the keyboard many times. This will show you where the cursor is. Another option to find the mouse cursor is to type "showcursor". This will bring up the mouse cursor on this power-up of the console.

About HARMAN Professional Solutions

HARMAN Professional Solutions is the world's largest professional audio, video, lighting, and control products and systems company. Our brands comprise AKG Acoustics[®], AMX[®], BSS Audio[®], Crown International[®], dbx Professional[®], JBL Professional[®], Lexicon Pro[®], Martin[®], and Soundcraft[®]. These best-in-class products are designed, manufactured and delivered to a variety of customers in markets including tour, cinema and retail as well as corporate, government, education, large venue and hospitality. For scalable, high-impact communication and entertainment systems, HARMAN Professional Solutions is your single point of contact. www.harman.com

exicon

Martin

Soundcraff

dbx

ετοωπ