

### vI.0 Cascade Mode on the Ui24R

3-Mar-23

Cascading audio between two (2) Ui24R's has been added to the v3.0 firmware.

- 32 channels of audio can be streamed each way between a HOST and REMOTE configured Ui24R unit.
- Each Ui24R in a cascade setup only has the ability to mix the actual channels that are passing through the unit.
- The GUI (user interface) does give you the ability to see all the channels on both HOST and REMOTE assigned Ui24R units, and sync VCA's and MUTE groups as well as Snapshots and Cues.

### **Connecting and Configuration Basics**

#### **Physical Connection Between Devices**

Directly connect the Ethernet 2 ports found on the side of each Ui24R together using a standard CAT5e or CAT6 Ethernet cable. This must be a direct connection. It will not work going through intermediate switches or routers.

Soundcraft has tested this connection up to 100 feet.

#### **IP Configuration**

Each Ui24R must have its LAN network IP address set to a unique address inside the same subnet. Login to each unit and configure their LAN IPs accordingly. For example, set one of the Ui24R units IPs to 192.168.1.80, and the other to 192.168.1.81. It is recommended that both Ethernet #I LAN ports are connected to an Gigabit Ethernet switch.

## Cascade Mode on the Ui24R

#### **GUI Configuration**

To use Cascade, the user must set the Cascade configuration on both the HOST and REMOTE Ui24R user interface.

HARM

#### HOST Ui24R

Login to the Ui24R GUI desired as HOST using it's IP address and set it to the following configuration.

SETTINGS->CASCADE->

- Set CASCADE mode to ON.
- Set ROLE to HOST.
- Set the REMOTE IP address to the IP address of your desired REMOTE Ui24R (192.168.1.81 in the example IP addresses above).
- Set the HOST's SYNC settings as desired. See the CASCADE SYNC Options section below for the remaining HOST settings and description.

BUIX/GAIN EDIT 3 AUXSENDS FXSENDS D O									Ui
				NETWORK	ACCESS	SHOWS	SETTINGS	PATCHING	ABOUT
					CASCADE	GLOBAL	LOCAL	GUI PERF	UTILITY
CASCADE:	OFF	ON							
ROLE:	REMOTE	HOST							
REMOTE IP:	192.168.1.81								
SYNC SNAPSHOT:	OFF	ON							
SYNC MUTE GROUPS:	OFF	ON							
SYNC VCA LEVELS:	OFF	ON							
CH24 INHERITS CASCADE SOLO:	OFF	ON							

# Cascade Mode on the Ui24R

#### **REMOTE Ui24R**

Login to the REMOTE Ui24R GUI using it's IP address and configure.

#### SETTINGS->CASCADE->

- Set CASCADE mode to ON.
- Set ROLE to REMOTE.



HARMA

### GUI Control

After Cascade features have been configured successfully in Settings, the user can access both HOST and REMOTE GUI's from a single browser window.

Open a browser window and navigate to the HOST Ui24R. Toggle the HOST/REMOTE button at the top of the GUI to toggle access between the HOST Ui24R and the REMOTE Ui24R.

AUXSENDS FXSENDS HOST	10W * Ui *
-19.7 dB -19.7 dB -14.2 dB -16.6 dB -18.0 dB -12.5 dB BA	INKS PLAYER FUNCTIONS
	< >
IIII MIX/GAIN EDIT I AUX SENDS FX SENDS REMOTE	bandi Ui
-8,9 dB -9.5 dB -5.3 dB -9.5 dB -14.1 dB -6.3 dB -15.8 dB -1.6 dB	BANKS PLAYER FUNCTIONS
	E LID

#### About HARMAN Professional Solutions

AKG AMX

HARMAN Professional Solutions is the world's largest professional audio, video, lighting, and control products and systems company. Our brands comprise AKG Acoustics<sup>®</sup>, AMX<sup>®</sup>, BSS Audio<sup>®</sup>, Crown International<sup>®</sup>, dbx Professional<sup>®</sup>, JBL Professional<sup>®</sup>, Lexicon Pro<sup>®</sup>, Martin<sup>®</sup>, and Soundcraft<sup>®</sup>. These best-in-class products are designed, manufactured and delivered to a variety of customers in markets including tour, cinema and retail as well as corporate, government, education, large venue and hospitality. For scalable, high-impact communication and entertainment systems, HARMAN Professional Solutions is your single point of contact. www.harman.com

dbx

HRI

exicon

Martin

Soundcraff